

LogEt6 Single-Use PDF Temperature Data Logger



General Description :

Elitech (UK) LogEt-6 This data logger is mainly used to record the temperature and humidity of food ,pharmaceuticals and chemicals , etc .in the storage and transportation.

It is widely applicable to each link in storage and logistics of cold chain, such as refrigerated container , refrigerator truck , cooler bag ,coo cabinet ,medicine cabinet ,cold storage ,laboratory ,etc.

Users can reconfigure parameters via the data management software. The reconfiguration will clear the original parameters and data (Only for LogEt 8)

The logger supports three upper limits and two lower limits

The range that is out of alarm thresholds

The logger records the single time for continuous out-of-limit events

The data logger records the cumulative time of all the out-of-limit events.

The logger does not alarm immediately when the temperature is within the alarm zone.

It begins to alarm

only when the alarm delay time elapses

Mean kinetic temperature is an evaluation method that indicates the effect of temperature fluctuation on stored articles

Operating Instructions

Action	Operation
Start the data logger	Press and hold the start button for about 5 seconds
Stop the data logger	Press and hold the stop button for about 5 seconds
Show status	Press and release the start button
Set Mark	Press and hold the start button for about 5 seconds



Specifications:

Technical Parameters :

Use Type	Single Use
Temperature measurement range	-30 C to +70 C
Temperature measurement accuracy	±0.5 C
Resolution	0.1 C
Data Capacity	16000 (MAX)
Shelf life / battery	2 years (stored and used under normal temperature environment)
Recording interval	10second to 12 Hour selectable
Protection class	IP65
Data interface	USB port
Report type	PDF format
Authenticate	CE, ROHS, GSP, EN12830
sensor type internal NTC thermistor	NTC thermistor
Battery	single-use 3.6V lithium battery