

TemLog ST-5 Single-Use PDF Temperature Data Logger



- ① USB & Protective Cap
- ② Button ③ Green LED ④ Red LED
- ⑤ Configuration Information

General Description :

Elitech (UK) TemLogSt-5 This data logger is mainly used to record the temperature and humidity of food ,pharmaceuticals and chemicals , etc .in the storage and transportation.

It is widely applicable to each link in storage and logistics of cold chain, such as refrigerated container , refrigerator truck , cooler bag ,coo cabinet ,medicine cabinet ,cold storage ,laboratory ,etc.

Operating Instructions

Action	Operation
Start the data logger	Press and hold the Red button for about 5 seconds Green LED flashes 5 times
Stop the data logger	Press and hold the stop button for about 5 seconds Red LED flashes 5 times
Not started	Red and green LEDs flash once time simultaneously
Start delay	Red and green LEDS flash once in turn
Started normal	Green LED flashes once per 10 seconds automatically
Started alarm	Red LED flashes once per 10 seconds automatically
Stopped normal	Green LED flashes two times
Stopped alarm	Red LED flashes two times



① USB Interface & Protective Cap

② Operating Mode

③ LED Indicator

④ Two-side Glue Sticker

⑤ Note

⑥ Certificates

Specifications:

Technical Parameters :

Use Type	Single Use
Temperature measurement range	-30 C to +70 C
Temperature measurement accuracy	±0.5 C
Resolution	0.1 C
Data Capacity	16000 (MAX)
Shelf life / battery	2 years (stored and used under normal temperature environment)
Recording interval	10second to 12 Hour selectable
Protection class	IP67
Data interface	USB port
Report type	PDF format
Authenticate	CE, ROHS, GSP, EN12830
sensor type internal NTC thermistor	Built- in NTC thermistor
Battery	single-use 3.6V lithium battery
Dimensions	80mm x 36mm x 10mm
Weight	Approx. 27 g